

20200902

Cleaning: Turn heater OFF and unplug from electrical outlet before any cleaning or maintenance is performed. Wait at least 10 minutes to allow all components to cool properly.

Technical Specification table with columns: Model (EF-1650), Voltage (220-240V~), Frequency (50 Hz), Power (1420-1650 W).

Disposal: Waste electrical production should not be disposed of with household waste. Please recycle where facilities exist. Check with your Local Authority or retailer for recycling advice.

16. ADVERTENCIA: este calefactor no está equipado con un dispositivo para controlar la temperatura ambiente. No use este calefactor en estancias pequeñas cuando las estén ocupando personas que no puedan salir de la habitación por sí mismas...

OPERATION BY THE CONTROL PANEL. The controls are located at the top of the fireplace. It takes some time for the receiver to respond to the transmitter. Do not PRESS the buttons more than once within two seconds for correct operation.

PANEL DE VISUALIZACIÓN. Includes diagrams of the control panel (Fig. A, B, C) and a table of technical specifications.

16. CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present. Helpful Advice before Fitting: Please retain all packaging until you have checked and counted all the parts and the contents of the hardware pack against the parts list.

lugar, pulse el botón «HOUR» (hora) y utilice los botones «+» y «-» para realizar el ajuste horario por hora. El exterior del calefactor debe limpiarse con un paño húmedo o un plumero.

Eliminación: Los productos eléctricos no deben desecharse con la basura doméstica. Recicle en las instalaciones correspondientes. Consulte con las autoridades locales o su distribuidor para obtener consejos de reciclaje.



KENTUCKY EAN 8436038136381 KT0813 Manual de instrucciones Instructions manual. Includes a photo of the fireplace and a barcode.

OPERATION BY THE REMOTE CONTROL. Remote control requires one 3V CR2025 Lithium Cell Battery (included). Remove the protective sheet between the battery and the contacts in order to operate.

Características del producto: Este es un calefactor eléctrico de simulación de llama. El funcionamiento del producto consiste en utilizar un ventilador para hacer circular el aire calentado por los elementos calefactores...

口径 尺寸：286X210

18. CAUTION - Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present. Helpful Advice before Fitting: Please retain all packaging until you have checked and counted all the parts and the contents of the hardware pack against the parts list.

Step4. Mount the fireplace on wall using the slots of the metal bracket at the back of the fireplace. See Fig. D. Make sure that the screw is completely engaged into the metal bracket at the back of the fireplace.

FUNCTIONAMIENTO MEDIANTE EL PANEL DE CONTROL. Los controles están situados en la parte superior del calefactor. El receptor tarda algún tiempo en responder al transmisor. Para permitir un funcionamiento correcto, no pulse los botones más de una vez en dos segundos.

FUNCTIONAMIENTO: Después de leer las instrucciones completas, compruebe que todos los controles del calefactor estén en la posición de apagado. Enchufe el calefactor a una toma de corriente de 15 A/220 V.

BOTÓN DEL CALEFACTOR: (1) AJUSTE DE MODO: pulse este botón para cambiar entre calor suave, calor intenso y apagado. (2) AJUSTE DE TEMPERATURA: en primer lugar, pulse el botón del calefactor en el modo de calefacción; seguidamente, pulse el botón «+» para aumentar la temperatura y el botón «-» para reducir la temperatura en el intervalo de entre 15 y 30 grados centígrados.

Features of the product: This is an emulational flame electric fireplace. The theory of the product is to use a fan to flow the hot air heated by the heating elements in order to achieve the effect of indoor heating.

Encendido del calefactor. Pulse este botón una vez y la llama se encenderá. La unidad se activará y podrá seleccionar las siguientes funciones como desee. Vuelva a pulsar este botón para apagar la unidad.

CONTROL REMOTO POR INFRAROJOS: Encendido del calefactor. Pulse este botón una vez y la llama se encenderá. La unidad se activará y podrá seleccionar las siguientes funciones como desee. Vuelva a pulsar este botón para apagar la unidad.

口径 尺寸：286X210